



Warning Tactile Indicators in the Urban Environment

Warning Tactile Indicators Defining a Pedestrian / Vehicle Shared Zone at the Same Grade with Bollards.

Example of an Obstruction Free Circulation Space

